
WIRING INSTRUCTIONS

SSB1002 SERIES MODULAR SWITCH BOX

- 1. Strip outer jacket of cable back 11/4 in. and remove all of the shielding.
- 2. Separate the internal wires from the shield and twist the shield drain wire.
- 3. Strip red and black insulation back 1/4 in.



4. Locate the appropriate plug, identified by channel number, remove the plug and install the wires using a small flathead screwdriver. Push plug back into location.

Orientation is as follows:

- a. Red insulated conductor wire is connected to (+).
- b. Black insulated conductor wire is connected to (-).
- c. Shield drain wire is connected to ground (GND).
- d. Depress selected position button on input terminal block to open terminal for respective wire

(May need mini flat head screwdriver).






<u>Visit our website</u> to download the full manual for SSB1002 enclosures.



WIRING INSTRUCTIONS

SSB1002 SERIES MODULAR SWITCH BOX



Sensor Inputs Red = Signal/Power (+) Black = Common (-) Grey = Shield (Ground)



